

Visual Site Inspection – Visually inspect the instruments for loose wiring, unusual noises from the aspirated shield fans, the correct orientation of instruments, etc. Report any problems directly to ATDD at 865-576-1233 or email at [Mark.E.Hall@noaa.gov](mailto:Mark.E.Hall@noaa.gov)

General Equipment Upkeep – The equipment, such as the anemometer, antennas, aspirated shields, battery and control boxes, solar radiation sensor and precipitation gauge, must be kept clear of wind blown debris, vermin nests and excrement.